





Denna ramtyp passar för att visa exempelvis fotografier

Tryckbyte



1. Lossa clipsen på baksidan
2. Ta bort ramen och byt Ditt tryckta material
3. Sätt tillbaks ramen och clipsen



Modell	Yttermått (mm)	Synlig yta (mm)	Postermått (mm)	Ljusstyrka (lux)	Vikt (kg)	Energiförbrukning (W)	Lampor (st)
A4	245 x 332 x 30	175 x 262	210 x 297	3500		12	2
A3	332 x 455 x 30	262 x 385	297 x 420	2500		12	2
A2	455 x 629 x 30	385 x 559	420 x 594	2000		12	2
A1	629 x 875 x 30	559 x 805	594 x 840	1500		24	4
A0	875 x 1223 x 30	805 x 1153	840 x 1188	1500		48	8
A00	1223 x 1715 x 30	1153 x 1645	1188 x 1680	1500		72	12
120 x 240	1235 x 2435 x 30	1165 x 2365	1200 x 2400	1500		96	16
20" x 30"	543 x 797 x 30	473 x 727	508 x 762	2000		24	4
24" x 36"	645 x 949 x 30	575 x 879	610 x 914	2500		48	8